

# On-Grid PV Inverter

Installation and Operation Manual

[www.aforeenergy.com](http://www.aforeenergy.com)



Version: S06018-01



Afore New Energy Technology (Shanghai) Co., Ltd.

T 86-21-54326236 F +86-21-54326136 E [info@aforeenergy.com](mailto:info@aforeenergy.com)

Ad Building 7, No.333 Wanfang Rd, Minhang District, Shanghai, China. 201112



Afore New Energy Technology (Shanghai) Co., Ltd.

# Contents

|                                                     |    |
|-----------------------------------------------------|----|
| 1. About This Manual . . . . .                      | 1  |
| 1.1 Scope of Validity . . . . .                     | 1  |
| 1.2 Target Group . . . . .                          | 1  |
| 1.3 System Diagram . . . . .                        | 1  |
| 2. Safety & Symbols . . . . .                       | 2  |
| 2.1 Safety Precautions . . . . .                    | 2  |
| 2.2 Explanations of Symbols . . . . .               | 3  |
| 3. Installation . . . . .                           | 4  |
| 3.1 Pre-installation . . . . .                      | 4  |
| 3.1.1 Unpacking & Package List . . . . .            | 4  |
| 3.1.2 Product Overview . . . . .                    | 5  |
| 3.1.3 Mounting Location . . . . .                   | 6  |
| 3.2 Mounting . . . . .                              | 7  |
| 4. Electrical Connection. . . . .                   | 8  |
| 4.1 PV Connection . . . . .                         | 8  |
| 4.2 Grid Connection . . . . .                       | 11 |
| 4.3 Communication Connection . . . . .              | 13 |
| 4.4 Zero-injection Smart Meter (Optional) . . . . . | 14 |
| 5. Operation . . . . .                              | 16 |
| 5.1 Control Panel . . . . .                         | 16 |
| 5.2 Menu Structure . . . . .                        | 17 |
| 5.3 Setting . . . . .                               | 18 |
| 5.3.1 Startup . . . . .                             | 18 |
| 5.3.2 Voltage Range . . . . .                       | 18 |
| 5.3.3 Frequency Range . . . . .                     | 19 |
| 6. Commissioning . . . . .                          | 20 |
| 7. Start-up & Shut Down . . . . .                   | 20 |
| 7.1 Shut down . . . . .                             | 20 |
| 7.2 Restart . . . . .                               | 20 |
| 8. Maintenance&Trouble Shooting . . . . .           | 21 |
| 8.1 Maintenance . . . . .                           | 21 |
| 8.2 Trouble Shooting . . . . .                      | 21 |
| 9. Specifications . . . . .                         | 25 |

# 1. About This Manual

## 1.1 Scope of Validity

This manual describes the installation, commissioning, operation and maintenance of the following on-grid PV inverters produced by Afore New Energy:

### Single-Phase(Two MPPT Trackers)

HNS3000TL      HNS3600TL      HNS4000TL      HNS5000TL  
HNS6000TL

### Single-Phase(One MPPT Tracker)

HNS3600TL-1


Please keep this manual all the time available in case of emergency.

## 1.2 Target Group

This manual is for qualified personnel. The tasks described in this manual must only be performed by qualified personnel.

## 1.3 System Diagram

The typical on-grid PV system connection diagram.



### Circuit Breaker Recommendation

| Type                             | Max AC Current (A) | Rated current of AC breaker (A) |
|----------------------------------|--------------------|---------------------------------|
| Single-Phase (Two MPPT Trackers) |                    |                                 |
| HNS3000TL                        | 15                 | 25                              |
| HNS3600TL                        | 18                 | 25                              |
| HNS4000TL                        | 20                 | 32                              |
| HNS5000TL                        | 23                 | 32                              |
| HNS6000TL                        | 28                 | 40                              |
| Single-Phase (One MPPT Tracker)  |                    |                                 |
| HNS3600TL-1                      | 18                 | 25                              |

### Surge Protector Recommendation

- AC side, nominal discharge current 20KA, second grade lightning protection, protection voltage 2.5KV.
- DC side, nominal discharge current 20KA, second grade lightning protection, protection voltage 3.2KV.
- The wiring distance between the inverter and the distribution box should be at least 5 meters.

#### Note:



The Inverter can be only connected to low-voltage grid.  
(220/230Vac, 50/60Hz).

## 2. Safety & Symbols

### 2.1 Safety Precautions

1. All work on the inverter must be carried out by qualified electricians.
2. The device may only be operated with PV panels.
3. The PV panels and inverter must be connected to the ground.
4. Do not touch the inverter cover until 5 minutes after disconnecting both DC and AC power supply.

5. Do not touch the inverter enclosure when operating, keep away from materials that may be affected by high temperatures.
6. Please ensure that the used device and any relevant accessories are disposed of in accordance with applicable regulations.
7. Afore inverter should be placed upwards and handled with care in delivery. Pay attention to waterproof. Do not expose the inverter directly to water, rain, snow or spray.
8. Alternative uses, modifications to the inverter not recommended. The warranty can become void if the inverter was tampered with or if the installation is not in accordance with the relevant installation instructions.

## 2.2 Explanations of Symbols

Afore inverter strictly comply with relevant safety standards. Please read and follow all the instructions and cautions during installation, operation and maintenance.



**Danger of electric shock**

The inverter contains fatal DC and AC power. All work on the inverter must be carried out by qualified personnel only.



**Beware of hot surface**

The inverter's housing may reach uncomfortably hot 60°C (140°F) under high power operation. Do not touch the inverter enclosure when operation.



**Residual power discharge**

Do not open the inverter cover until 5 minutes after disconnection both DC and AC power supply.



**Important notes**

Read all instructions carefully. Failure to follow these instructions, warnings and precautions may lead to device malfunction or damage.



**Do not dispose of this device with the normal domestic waste.**



**Without transformer**

This inverter does not use transformer for the isolation function.



**CE mark**

The inverter complies with the requirements of the applicable CE guidelines.



**Refer to manual before service.**

## 3. Installation

### 3.1 Pre-installation


#### 3.1.1 Unpacking & Package List

##### Unpacking

On receiving the inverter, please check to make sure the packing and all components are not missing or damaged. Please contact your dealer directly for supports if there is any damage or missing components.

##### Package List

Open the package, please check the packing list shown as below.




| No. | Qty | Items                               | No. | Qty | Items                                      |
|-----|-----|-------------------------------------|-----|-----|--------------------------------------------|
| 1   | 1   | Solar inverter                      | 8   | 3   | Plastic Expansion Tube                     |
| 2   | 1   | Certificate Of Inspection           | 9   | 3   | Tapping Screw                              |
| 3   | 1   | Quick Installation Instructions     | 10  | 1   | Security Screw                             |
| 4   | 1   | Warranty Card                       | 11  | 1/2 | DC Connector sets                          |
| 5   | 1   | Wall Mounting Bracket               | 12  | 1   | Monitor Module                             |
| 6   | 1   | AC Connector                        | 13  | 1   | Monitoring Quick Installation Instructions |
| 7   | 1   | Zero-Injection Connector (Optional) |     |     |                                            |

##### Note:




The HNS3600TL-1 is 1 pair of DC plug connector, the HNS3000-6000TL is 2 pairs.

### 3.1.2 Product Overview



#### Inverter Terminals




| No. | Items                              |
|-----|------------------------------------|
| 1   | DC Switch                          |
| 2   | DC Connectors ( + ) For PV Strings |
| 3   | DC Connectors ( - ) For PV Strings |
| 4   | AC Connector                       |
| 5   | Monitor Module Port                |
| 6   | Zero-Injection Port (Optional)     |


### 3.1.3 Mounting Location

The inverters are designed for indoor and outdoor installation (IP65), to increase the safety, performance and lifespan of the inverter, please select the mounting location carefully based on the following rules:

- The inverter should be installed on a solid surface, far from flammable or corrosion materials, where is suitable for inverter's weight and dimensions.
- The ambient temperature should be within  $-25^{\circ}\text{C} \sim 60^{\circ}\text{C}$  (between  $-13^{\circ}\text{F}$  and  $140^{\circ}\text{F}$ ).
- The installation of inverter should be protected under shelter. Do not expose the inverter to direct sunlight, water, rain, snow, spray lightning, etc.




- The inverter should be installed vertically on the wall, or lean back on plane with a limited tilted angle. Please refer to below picture.







- Leave the enough space around inverter, easy for accessing to the inverter, connection points and maintenance.






### 3.2 Mounting

#### Step 1



#### Step 2



**Step 3**

## 4. Electrical Connection

### 4.1 PV Connection

The inverter is equipped with 2 MPPT channels, each of which contains a PV string input.

For the best results, make sure that each MPPT channel is correctly connected with PV string. Otherwise, the inverter will activate voltage or current protection automatically.

Please make sure below requirements are followed:


- The open-circuit voltage and short-circuit current of PV string should not exceed the reasonable range of the inverters.
- The isolation resistance between PV string and ground must exceed 10 k $\Omega$ .
- The polarity of PV strings are correct.
- Use the DC plugs in the accessory.
- The lightning protector should be equipped between PV string and inverter.
- Disconnect all of the PV (DC) switch during wiring.

**Warning:**

The fatal high voltage may on the DC side, please comply with electric safety when connecting.

Please make sure the correct polarity of the cable connected with inverter, otherwise inverter could be damaged.


**Step 1**



**Note:**

PV cable suggestion  
Cross-section  
4mm<sup>2</sup>


**Step 2**



**Note:**


Please use PV connector crimper to pinch the point of the arrow.


**Step 3**



**Note:**


You'll hear click sound when the  
connector assembly is correct.



 **Note:**  
PV string suggestion:


 **Correct Installation:**

Channel A and B connected with PV strings separately



 **Wrong Installation:**

Do not connect more than two PV strings into one channel



## 4.2 Grid Connection

The external AC switch should be installed between inverter and grid to isolate from grid. Please make sure below requirements are followed before connecting AC cable to the inverter.


- The AC (grid) voltage should not exceed the reasonable range of the inverters.
- The phase-line from AC distribution box are correctly connected.
- Use the AC plugs in the accessory.
- The surge protector should be equipped between grid and inverter.
- Disconnect the AC (grid) switch during wiring.



### Warning:

The fatal high voltage may on the AC side, please comply with electric safety when connecting.  
Please make sure the right line of AC grid connected with inverter, otherwise inverter could be damaged.


#### Step 1



### Note:

AC cable suggestion  
Cross-section  
4mm<sup>2</sup>


#### Step 2



### Note:


AC line goes through AC terminal waterproof head and cap

**Step 3**



Connect AC line, Live line (L), Neutral line (N) and Ground Wire (PE) according to polarity.

**Step 4**



1. Connect AC terminals and waterproof head, tighten the cap, make sure they clip closely together.
2. Connect AC connector to AC terminal of the inverter.
3. After making sure that it is firmly inserted, tighten the sleeve on the AC connector to the right and hear a click.




## 4.3 Communication Connection

The monitoring module could transmit the data to the cloud server, and display the data on the PC, tablet and smart-phone.


### Install the WIFI / Ethernet / GPRS / RS485 Communication

WIFI / Ethernet / GPRS / RS485 communication is applicable to the inverter. Please refer to "Communication Configuration Instruction" for detailed instruction.

#### Step 1




#### Step 2



## 4.4 Zero-injection Smart Meter (Optional)

Smart meter is an intelligent control equipment which is used for on-grid inverters. Its main function is to measure the forward and reverse power on the grid-connected side, and transmit data to the inverter through RS485 communication to ensure that the power of the inverter is less than or equal to the user's home load, and no current flows into the grid.

### Step 1




### Note:

For single-phase inverter, please follow below pin order  
 RS485A(Pin 7) to single-phase meter (Pin 24)  
 RS485B(Pin 8) to single-phase meter (Pin 25)




**Step 2**



**Note:**

Please refer to "Zero Injection Smart Meter Installation and Operation Manual" for detailed instruction.




**Note:**

The Inverter could be connected in parallel with Smart Meter, make sure the total load power not exceed Smart Meter's limitation.

## 5. Operation


### 5.1 Control Panel



| No. | Items                    | No. | Items                      |
|-----|--------------------------|-----|----------------------------|
| 1   | LCD Display              | 5   | <b>ENT</b> Touch Button    |
| 2   | <b>UP</b> Touch Button   | 6   | <b>POWER</b> LED Indicator |
| 3   | <b>DOWN</b> Touch Button | 7   | <b>GRID</b> LED Indicator  |
| 4   | <b>ESC</b> Touch Button  | 8   | <b>FAULT</b> LED Indicator |

| Sign         | Power | Color | Explanation                       |
|--------------|-------|-------|-----------------------------------|
| <b>POWER</b> | ON    | Green | The inverter is stand-by          |
|              | OFF   |       | The inverter is power off         |
| <b>GRID</b>  | ON    | Green | The inverter is feeding power     |
|              | OFF   |       | The inverter is not feeding power |
| <b>FAULT</b> | ON    | Red   | Fault occurred                    |
|              | OFF   |       | No fault                          |

## 5.2 Menu Structure




## Explanation of LCD Display Content


| Nouns           | Explanation                                                |
|-----------------|------------------------------------------------------------|
| Inverter Info   | Display the serial number and firmware version of inverter |
| Error Record    | Check the error list of inverter including date and time   |
| Wifi Info       | Display the WIFI serial number and assigned IP address     |
| Date & Time     | Set date and time of the inverter                          |
| Setting         | Set the protection parameters of inverter                  |
| Function Enable | Countercurrent power switch                                |
| Zero Injection  | Meter switch                                               |


## 5.3 Setting

### 5.3.1 Startup




### 5.3.2 Voltage Range





### 5.3.3 Frequency Range



**Note:**

The parameters setting only works after the inverter is restarted.

## 6. Commissioning

Before starting up commissioning at site, please make sure below procedures and requirements are fully meet.

- Mounting location is meet the requirements.
- All of the electrical wiring is firmly connected, including PV wiring, Grid wiring and Earth wiring.
- The inverter setting has been finished accordingly to local standards or regulations.

### Commissioning Procedures

- Turn on the AC switch between inverter output and the public grid;
- Turn on the DC switch on the inverter;
- Turn on the PV switch of the system.

## 7. Start-up & Shut Down

### 7.1 Shut down

- Turn off the DC switch on the inverter.
- Turn off the DC switch between PV panels and the inverter (if any).
- Close the AC switch between the inverter and the public grid.

**Note:**

The inverter will be operable after minimum 5 minutes.

### 7.2 Restart

- Shut down the inverter according to Chapter 7.1.
- Start-up the inverter according to Chapter 6.

## 8. Maintenance&Trouble Shooting

### 8.1 Maintenance

Periodically maintenance are necessary, please follow steps as below.

PV connection: twice a year

AC connection : twice a year

Earth connection: twice a year

Heat sink: clean with dry towel once a year.

### 8.2 Trouble Shooting

Fault messages will be displayed when fault occurs, please according to trouble- shooting table find related solutions.

## Trouble-Shooting List

| Type of Fault | Name             | Description                                                                                  | Recommend Solution                                                                                                                                                                                                                                                                         |
|---------------|------------------|----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PV Fault      | Isolation Fault  | The impedance between ground and PV (+) & PV (-) is too low, beyond the reasonable range.    | <ul style="list-style-type: none"> <li>• Check whether the battery and wiring are immersed in water and whether the insulation layer is damaged, and then make corrections.</li> <li>• If the fault occurs continuously and frequently, please ask help for local distributors.</li> </ul> |
|               | PV Volt Low      | The DC input voltage from PV strings is below the minimum reasonable value.                  | <ul style="list-style-type: none"> <li>• Reconfigure the PV strings by increasing the number of PV strings to increase DC input voltage.</li> <li>• Contact local distributors for suggestions and solutions.</li> </ul>                                                                   |
|               | PV Volt High     | The DC input voltage from PV strings is exceeding the maximum reasonable value.              | <ul style="list-style-type: none"> <li>• Reconfigure the PV strings by reducing the number of PV strings to decrease DC input voltage.</li> <li>• Contact local distributors for suggestions and solutions.</li> </ul>                                                                     |
|               | PV1 Over Current | PV1 current is too high, protection is triggered.                                            | <ul style="list-style-type: none"> <li>• Power off, then restart (Ref. Chapter6)</li> <li>• If fault still occurs continuously and frequently, please ask help for local distributors.</li> </ul>                                                                                          |
|               | PV2 Over Current | PV2 current is too high, protection is triggered.                                            |                                                                                                                                                                                                                                                                                            |
| Grid Fault    | Island Fault     | The public grid is outage or the grid is disconnected to the inverter.                       | <ul style="list-style-type: none"> <li>• The fault will disappear automatically when the public grid go back to normal.</li> <li>• Contact the local distributor or grid company to adjust the voltage protection parameters.</li> </ul>                                                   |
|               | 10min Over Volt  | The 10-minute average value of the grid voltage is abnormal and beyond the protection range. | <ul style="list-style-type: none"> <li>• Power off, then restart (Ref. Chapter6)</li> <li>• If fault still occurs continuously and frequently, please ask help for local distributors.</li> </ul>                                                                                          |
|               | Grid Volt Fault  | Grid voltage is abnormal, beyond the protection range.                                       | <ul style="list-style-type: none"> <li>• The fault will disappear automatically when the grid voltage is back to normal.</li> <li>• If fault still occurs continuously and frequently, please ask help for local distributors.</li> </ul>                                                  |
|               | Grid Freq Fault  | Grid frequency is abnormal, beyond the protection range.                                     | <ul style="list-style-type: none"> <li>• The fault will disappear automatically when the grid frequency is back to normal.</li> <li>• If fault still occurs continuously and frequently, please ask help for local distributors.</li> </ul>                                                |



| Type of Fault | Name             | Description                                                                                          | Recommend Solution                                                                                                                                                                                                                                                                                                                                 |
|---------------|------------------|------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DC Fault      | Bus Low Fault    | When inverter is running, bus voltage is lower than the normal value beyond the protection range.    | <ul style="list-style-type: none"> <li>• Power off, then restart (Ref. Chapter6)</li> <li>• If fault still occurs continuously and frequently, please ask help for local distributors.</li> </ul>                                                                                                                                                  |
|               | Bus High Volt    | Bus voltage is too high and beyond the protection range.                                             |                                                                                                                                                                                                                                                                                                                                                    |
|               | Bus Unbalance    | Bus voltage unbalanced, beyond the protection range.                                                 |                                                                                                                                                                                                                                                                                                                                                    |
|               | DC Offset Fault  | The DC component of grid-connected current is too high that beyond the reasonable range.             |                                                                                                                                                                                                                                                                                                                                                    |
| System Fault  | Over Temperature | The temperature of the installation environment is too high or too low, beyond the reasonable range. | <ul style="list-style-type: none"> <li>• Improve or change the installation environment to adjust the inverter installation environment temperature to normal range.</li> <li>• Power off, then restart (Ref. Chapter6)</li> <li>• If fault still occurs continuously and frequently, please ask help for local distributors.</li> </ul>           |
|               |                  | The temperature of the cooling device is high or low that beyond the protection range.               |                                                                                                                                                                                                                                                                                                                                                    |
|               |                  | The temperature of the CPU is high that beyond the protection range.                                 |                                                                                                                                                                                                                                                                                                                                                    |
|               | Auto Test Fail   | Automatic test failed.                                                                               | <ul style="list-style-type: none"> <li>• Power off the inverter to check the AC connection, then restart.</li> <li>• If fault still occurs continuously and frequently, please ask help for local distributors.</li> </ul>                                                                                                                         |
|               | No Utility       | No continuous utility                                                                                |                                                                                                                                                                                                                                                                                                                                                    |
|               | Grid Volt AD     | Grid voltage AD value deviation is too high, beyond the protection range.                            | <ul style="list-style-type: none"> <li>• Power off, then restart (Ref. Chapter6)</li> <li>• If fault still occurs continuously and frequently, please ask help for local distributors.</li> </ul>                                                                                                                                                  |
|               | Self Lock        | Inverter is locked at the waiting interface.                                                         |                                                                                                                                                                                                                                                                                                                                                    |
|               | Consistent Fault | The detection results of the two CPUs for the same voltage and frequency are different.              |                                                                                                                                                                                                                                                                                                                                                    |
|               | Device Fault     | Grounding is abnormal or the ground wire is disconnected.                                            | <ul style="list-style-type: none"> <li>• Check whether the ground wire of the inverter is properly connected and the ground impedance is too high, if it is, make corrections.</li> <li>• Power off, then restart (Ref. Chapter6)</li> <li>• If fault still occurs continuously and frequently, please ask help for local distributors.</li> </ul> |

| Type of Fault | Name               | Description                              | Recommend Solution                                                                                                                                                                                |
|---------------|--------------------|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Inner Warning | Fan Fault          | The fan can not work when is started up. | <ul style="list-style-type: none"> <li>• Check if there is objects which blocking the fan rotation and remove it.</li> </ul>                                                                      |
|               | Eeprom Fault       | Eeprom abnormal                          | <ul style="list-style-type: none"> <li>• Power off, then restart (Ref. Chapter6)</li> <li>• If fault still occurs continuously and frequently, please ask help for local distributors.</li> </ul> |
|               | Communication Lose | CPU to Flash abnormal                    |                                                                                                                                                                                                   |
|               |                    | CPU to Eeprom abnormal                   |                                                                                                                                                                                                   |
|               |                    | Main CPU to auxiliary abnormal           |                                                                                                                                                                                                   |
|               |                    | Main CPU to HMI abnormal                 |                                                                                                                                                                                                   |

## 9. Specifications

| PV Input Data                            | HNS3600TL-1                                                                                                                                                                     | HNS3000TL | HNS3600TL | HNS4000TL | HNS5000TL | HNS6000TL |
|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|-----------|-----------|-----------|-----------|
| Max. DC Power ( W )                      | 4200                                                                                                                                                                            | 4500      | 5400      | 6000      | 7000      | 8400      |
| Max. DC Voltage ( V )                    | 600                                                                                                                                                                             | 600       | 600       | 600       | 600       | 600       |
| MPPT Voltage Range ( V )                 | 70-500                                                                                                                                                                          | 70-550    | 70-550    | 70-550    | 70-550    | 70-550    |
| MPPT Full Power Voltage Range ( V )      | 130-500                                                                                                                                                                         | 110-550   | 130-550   | 145-550   | 180-550   | 220-550   |
| Rated Input Voltage ( V )                | 360                                                                                                                                                                             | 360       | 360       | 360       | 360       | 360       |
| Start-up Voltage ( V )                   | 70                                                                                                                                                                              | 70        | 70        | 70        | 70        | 70        |
| Max. Input Current ( A )                 | 14                                                                                                                                                                              | 14 x 2    | 14 x 2    | 14 x 2    | 14 x 2    | 14 x 2    |
| Max. Short Current ( A )                 | 18                                                                                                                                                                              | 18 x 2    | 18 x 2    | 18 x 2    | 18 x 2    | 18 x 2    |
| No. of MPP Tracker /<br>No. of PV String | 1/1                                                                                                                                                                             | 2/2       | 2/2       | 2/2       | 2/2       | 2/2       |
| Input Connector Type                     | MC4                                                                                                                                                                             | MC4       | MC4       | MC4       | MC4       | MC4       |
| AC Output Data                           | HNS3600TL-1                                                                                                                                                                     | HNS3000TL | HNS3600TL | HNS4000TL | HNS5000TL | HNS6000TL |
| Max. Output Power ( W )                  | 3960                                                                                                                                                                            | 3300      | 3960      | 4400      | 5500      | 6600      |
| Nominal Output Power ( W )               | 3600                                                                                                                                                                            | 3000      | 3600      | 4000      | 5000      | 6000      |
| Max. Output Current ( A )                | 17.5                                                                                                                                                                            | 15        | 17.5      | 20        | 24        | 28.7      |
| Nominal Output Voltage ( V )             | L/N/PE, 220Vac, 230Vac, 240Vac                                                                                                                                                  |           |           |           |           |           |
| Grid Voltage Range                       | 180Vac-276Vac (According to local standard)                                                                                                                                     |           |           |           |           |           |
| Nominal Output Frequency ( Hz )          | 50/60                                                                                                                                                                           |           |           |           |           |           |
| Grid Frequency Range                     | 45~55Hz/54~66Hz (According to local standard)                                                                                                                                   |           |           |           |           |           |
| Output Power Factor                      | 1 default (adjustable from 0.8 leading to 0.8 lagging)                                                                                                                          |           |           |           |           |           |
| Output Current THD                       | <3%                                                                                                                                                                             |           |           |           |           |           |
| Efficiency                               | HNS3600TL-1                                                                                                                                                                     | HNS3000TL | HNS3600TL | HNS4000TL | HNS5000TL | HNS6000TL |
| Max. Efficiency                          | 98.20%                                                                                                                                                                          | 98.20%    | 98.20%    | 98.20%    | 98.20%    | 98.20%    |
| Euro Efficiency                          | 97.80%                                                                                                                                                                          | 97.80%    | 97.82%    | 97.85%    | 97.90%    | 97.92%    |
| Protection                               | HNS3600TL-1                                                                                                                                                                     | HNS3000TL | HNS3600TL | HNS4000TL | HNS5000TL | HNS6000TL |
| PV Reverse Polarity Protection           | YES                                                                                                                                                                             | YES       | YES       | YES       | YES       | YES       |
| PV Insulation Resistance Detection       | YES                                                                                                                                                                             | YES       | YES       | YES       | YES       | YES       |
| AC Short Circuit Protection              | YES                                                                                                                                                                             | YES       | YES       | YES       | YES       | YES       |
| AC Over Current Protection               | YES                                                                                                                                                                             | YES       | YES       | YES       | YES       | YES       |
| AC Over Voltage Protection               | YES                                                                                                                                                                             | YES       | YES       | YES       | YES       | YES       |
| Anti-Islanding Protection                | YES                                                                                                                                                                             | YES       | YES       | YES       | YES       | YES       |
| Residual Current Detection               | YES                                                                                                                                                                             | YES       | YES       | YES       | YES       | YES       |
| Over Temperature Protection              | YES                                                                                                                                                                             | YES       | YES       | YES       | YES       | YES       |
| Integrated DC switch                     | YES                                                                                                                                                                             | YES       | YES       | YES       | YES       | YES       |
| Surge Protection                         | Integrated (Type III)                                                                                                                                                           |           |           |           |           |           |
| General Data                             | HNS3600TL-1                                                                                                                                                                     | HNS3000TL | HNS3600TL | HNS4000TL | HNS5000TL | HNS6000TL |
| Dimensions (W x H x D, mm)               | 358x360x142                                                                                                                                                                     |           |           |           |           |           |
| Weight ( kg )                            | 10                                                                                                                                                                              |           |           |           |           |           |
| Protection Degree                        | IP65                                                                                                                                                                            |           |           |           |           |           |
| Enclosure Material                       | Aluminum                                                                                                                                                                        |           |           |           |           |           |
| Ambient Temperature Range (°C)           | -25 ~ +60°C (Derating 45°C)                                                                                                                                                     |           |           |           |           |           |
| Humidity Range                           | 0-100%                                                                                                                                                                          |           |           |           |           |           |
| Topology                                 | Transformerless                                                                                                                                                                 |           |           |           |           |           |
| Communication Interface                  | RS485 / WiFi / Wire Ethernet / GPRS (optional)                                                                                                                                  |           |           |           |           |           |
| Cooling Concept                          | Convection                                                                                                                                                                      |           |           |           |           |           |
| Noise Emission ( db )                    | <28                                                                                                                                                                             |           |           |           |           |           |
| Night Power Consumption ( W )            | <1                                                                                                                                                                              |           |           |           |           |           |
| Max. Operation Altitude ( m )            | 4000                                                                                                                                                                            |           |           |           |           |           |
| Certifications and Standards             | HNS3600TL-1                                                                                                                                                                     | HNS3000TL | HNS3600TL | HNS4000TL | HNS5000TL | HNS6000TL |
| EMC Standard                             | EN/IEC 61000-6-2, EN/IEC 61000-6-3, EN61000-3-2, EN61000-3-3, EN61000-3-11, EN61000-3-12                                                                                        |           |           |           |           |           |
| Safety Standard                          | IEC 60068, IEEE1547, EN62109                                                                                                                                                    |           |           |           |           |           |
| Grid-connection                          | EN50549-1, EN50438, RD 1699, UNE 217001, RD 413, IEC61727, IEC62116, IEC61683, VDE4105, UL1741 VDE0126 AS4777.2 NB/T 32004-2018, UNT C 15-712-1, ABNT NBR 16149, ABNT NBR 16150 |           |           |           |           |           |