

VIKTIG

Ikke koble til et apparat der belastningen overstiger 16 Amp. Forsikre deg alltid om at støpselet er satt helt inn i tidsuret. Hvis rengjøring av tidsuret er nødvendig, må du fjerne det fra strømuttaket og tørke av med en tørr klut.

IKKE DYPP TIDSURET I VANN ELLER ANDRE VÆSKER.

Varmeapparater og lignende apparater skal aldri etterlates uten tilsyn under drift. Produsenten anbefaler at slike apparater ikke kobles til tidsuret.

KORT INTRODUKSJON

1. Tidsuret har totalt 8 PÅ / AV-programmer.
2. MANUAL ON / AUTO / MANUAL OFF kan gjøre innstillinger etter behov veldig enkelt.
3. 12/24 timers modus kan byttes.
4. Sommertid funksjonen er veldig nyttig i områder med sommertid.
5. 16 kombinasjoner av dag eller blokker av dager er tilgjengelige for dette tidsuret som følger:
6. Tilfeldig funksjon for å gjøre innstillingene utført med en tilfeldig forsinkelse på 0-32 minutter.

Mo

Tu

Vi

Th

Fr

Sa

Su

Mo, Tu, We, Th, Fr, Sa, Su

Mo, Tu, We, Th, Fr

Sa, Su

Mo, Tu, We, Th, Fr, Sa

Mo, vi, Fr

Tu, Th, Sa

Mo, Tu, vi

Th, Fr, Sa

Mo, We, Fr, Su

GRUNNLEGGENDE DRIFT

1. Koble tidsuret til et vanlig strømuttak på 230/240 volt og slå på strømmen.
2. La stå i omtrent 12 timer for å lade Memory Backup-batteriene.
3. Etter lading, slett all aktuell informasjon ved å trykke på MASTER CLEAR-knappen med en skarp gjenstand som en penn eller blyant.
4. Tidsuret er nå klar til å settes opp for bruk.

INNSTILLING AV AKTUELL TID

1. Trykk på CLOCK-knappen og hold den nede, og trykk samtidig på WEEK-knappen til den faktiske dagen vises. Fortsett ved å trykke på HOUR eller MINUTE-knappen til gjeldende time eller minutt vises. Når du stiller inn, kan knappene UKE, HOUR eller MINUTE holdes nede for rask fremtelling.
2. Slipp begge knappene. Uke og tid vil bli satt.
3. Gjenta forrige trinn for å tilbakestille feil tid.

INNSTILLINGSPROGRAMMER

1. Trykk på TIMER-knappen og slipp den. Den første PÅ-innstillingen kan gjøres nå.
2. Trykk på WEEK-knappen for å stille inn dagen eller dagblokkene. Still inn tiden ved å trykke på HOUR-knappen og deretter på MINUTE-knappen.
3. Trykk på TIMER-knappen igjen for å fullføre den første PÅ-innstillingen og gå inn i den første AV-innstillingen. Gjenta 2 for å foreta den første OFF-innstillingen.
4. Trykk på TIMER-knappen igjen for å fullføre den første AV-innstillingen og gå inn i den andre PÅ-innstillingen. Gjenta 2 og 3 for å programmere gjenværende innstilling.
5. Når du har fullført innstillingene, trykker du på CLOCK-knappen og TIMER er klar til bruk.

EKSEMPEL: TIMER PÅ kl 18:15 og TIMER AV kl 22:15 hver dag

- a. Trykk på TIMER og LCD-skjermen viser 1_ON
- b. Trykk på WEEK til LCD-skjermen viser "MO, TU, WE, TH, FR, SA, SU"
- c. Trykk på HOUR til LCD-skjermen viser 18:00
- d. Trykk på MINUTE til LCD-skjermen viser 18:15
- e. Trykk på TIMER igjen og LCD-skjermen viser 1_OFF
- f. Gjenta ovenstående c. og d. til LCD viser 22:15 eller 22:15
- g. Trykk på knappen "RES / RCL" for å stoppe noen programmer, trykk på knappen "RES / RCL" igjen for å hente frem de selektive programmene.

MANUAL ON / AUTO / MANUAL OFF SETTING

1. Trykk PÅ / AUTO / AV-knappen for å tilbakestille de tre modusene etter tur.
2. I MANUAL ON eller MANUAL OFF-modus fungerer ikke tidsuret som innstillinger i AUTO-modus.
3. Når modusen er slått fra MANUELL TIL AUTO, vil tidsuret beholde innstillingen for MANUAL til neste timerinnstilling.

12 / 24TIMEMODUS

Trykk CLOCK og TIMER samtidig for å slå mellom 12 og 24 timers modus.

SOMMERTIDSFUNKSJON

1. Trykk på knappene CLOCK og ON / AUTO / OFF samtidig i AUTO-modus. LCD-skjermen viser SOMMER.
2. Klokken stilles tilbake en time.
3. Trykk på de to knappene igjen for å gå tilbake til vintertid.

SPESIFIKASJONER

Spenning 230V ~ 50Hz

Maks belastning 16A, 3500W

Min innstillingstid 1 minutt

Driftstemperatur -10 til + 40 °C

Nøyaktighet +/- 1 minutt per måned

Batteribackup NIMH 1.2V> 100 timer

hamron 1402704 ED1#200723 SY IMPORTANT Don't plug in an appliance where the load exceeds 16 Amp. Always ensure the plug of any appliance is fully inserted into the timer outlet. If cleaning of the timer is required, remove from mains power and wipe timer with a dry cloth. DO NOT IMMERSE TIMER IN WATER OR ANY OTHER LIQUID. Heaters and similar appliances should never be left unattended during operation. The manufacturer recommends such appliances not be connected to timers. BRIEF INTRODUCTION - The Timer has a total of 8 ON/OFF programs. - MANUAL ON/AUTO/MANUAL OFF can make settings as required very easily. 12/24 hour mode is switchable. - Summertime function is very useful for areas with summertime system. 16 combinations of day or blocks of days are available for this Timer as follows: - Random function to make the settings executed with a random delay of 0-32 minutes. Mo Tu We Th Fr Sa Su Mo, Tu, We, Th, Fr, Sa, Su Mo, Tu, We, Th, Fr Sa, Su Mo, Tu, We, Th, Fr, Sa Mo, We, Fr Tu, Th, Sa Mo, Tu, We Th, Fr, Sa Mo, We, Fr, Su INITIAL OPERATION - Plug the Timer into a regular 230/240 Volt household power point and turn the power on. - Leave for approximately 12 hours to charge the Memory Back Up batteries. - After charging clear all current information by pressing the MASTER CLEAR button with a sharp object such as a pen or pencil. - The timer is now ready to be set up for use. SETTING CURRENT TIME - Press the CLOCK button and hold, simultaneously press the WEEKbutton until the actual day is displayed. Continue by pressing HOUR or MINUTE button until the current hour or minute is displayed. When setting, the buttons WEEK, HOURor MINUTE can be held down for rapid forward counting. - Release both buttons. The week and time will be set. - To reset incorrect time, repeat previous steps. SETTING PROGRAMS - Press the TIMER button and release. The first ON setting can be made now. - Press WEEK button to set the day or blocks of days. Set the time by pressing the HOUR button and then MINUTE button. - Press the TIMERbutton again to finish the first ON setting and enter into the first OFF setting. By repeating 2 to make the first OFF setting. - Press the TIMER button again to finish the first OFF setting and enter into the 2nd ON setting. Repeating 2 and 3 to program remaining setting.	- After completing settings, press the CLOCK button and the TIMER is ready to operate. EXAMPLE: TIMER ON at 18:15 and TIMER OFF at 22:15 everyday - Press TIMER and LCD displays 1_ON - Press WEEK till LCD displays “MO, TU, WE, TH, FR, SA, SU” - Press HOUR till LCD displays 6:00PM or 18:00 - Press MINUTE till LCD displays 6:15PM or 18:15 - Press TIMER again and LCD displays 1_OFF - Repeat the above c. and d. till LCD displays 10:15PM or 22:15 - Press the button “RES/RCL” to stop some programs, press the button “RES/RCL” again to recall the selective programs. Regulate completely. It will cancel some design or recall to make some design which has been cancelled while pressing the key RESET/RECALL. TIP: When verifying your programs ensure that the settings do not overlap, especially when using the block option. MANUAL ON/AUTO/MANUAL OFF SETTING - Press ON/AUTO/OFF button to revert the three mode in turn. - IN MANUAL ON or MANUAL OFF mode the Timer doesn't operate as settings in AUTO mode. - When the mode is turned from MANUAL TO AUTO, the Timer will keep the setting of MANUAL until to the next timer setting. 12/24HOUR MODE Press CLOCK and TIMER simultaneously to turn between 12 and 24 Hour mode. SUMMERTIME FUNCTION - Press the buttons CLOCK and ON/AUTO/OFF simultaneously in AUTO mode. The LCD will show SUMMER. - The clock will set back one hour. - Press the two buttons again to revert to Wintertime. SPECIFICATIONS <table> <tr> <td>Voltage</td><td>230V~ 50Hz</td></tr> <tr> <td>Max Load</td><td>16A, 3500W</td></tr> <tr> <td>Min Setting Time</td><td>1Minute</td></tr> <tr> <td>Operating temperature</td><td>-10 to +40℃</td></tr> <tr> <td>Accuracy</td><td>+/-1minute per month</td></tr> <tr> <td>Battery backup</td><td>NIMH 1.2V >100hours</td></tr> </table>	Voltage	230V~ 50Hz	Max Load	16A, 3500W	Min Setting Time	1Minute	Operating temperature	-10 to +40℃	Accuracy	+/-1minute per month	Battery backup	NIMH 1.2V >100hours
Voltage	230V~ 50Hz												
Max Load	16A, 3500W												
Min Setting Time	1Minute												
Operating temperature	-10 to +40℃												
Accuracy	+/-1minute per month												
Battery backup	NIMH 1.2V >100hours												