

Wi-Fi Guide


1. Download APP

You can download the app by searching for Smart Life in your app store or by scanning the following QR code:



2. Registration


Open the Smart Life App, register an account: you can use either your phone number or email address to register. Agree to the user agreements and press “Get Verification Code” to receive a code to the provided number/email address. Enter the verification code and then set your own password. Use your password to log in.



3. Add and connect the device


Insert the power plug and turn on the power switch, the product enter standby mode, press “On/Off Button” 3s the icon “” will flash.

1) Press “+” icon in the upper right corner of the page or the “Add Device” button in the middle page to start adding the device.



2) There are 2 methods to connecting to the service:






Method 1: Press “Add” button in the middle page (you need to keep your phone Bluetooth on). Then enter the Wi-Fi password . Press “next” to start connecting. (Only 2.4GHz Wi-Fi is supported. Please make sure your Wi-Fi is 2.4GHz.)




Method 2: Under “Add Manually”, choose “Small Home appliance”(you need to keep your phone Bluetooth on)).

Then choose “Baseboard Heater BLE+Wi-Fi”. (For iOS system, you need turn on local network access.) Enter the Wi-Fi password. Press “Next”. Make sure you have connected to the Wi-Fi successfully and that the Wi-Fi indicator blinks. Press ”Confirm the indicator is blinking” and then choose “Blink Quickly” to start connecting. (Only 2.4GHz Wi-Fi is supported. Please make sure your Wi-Fi is 2.4GHz)

This page applies only for iOS system






4. Connect successfully

When the device is successfully connected, the Wi-Fi icon will stop flashing and keep on (including standby mode). The App will show “Device added successfully”.

Press “done” to start your operation for the appliance over your phone.



Notes:

- 1) If there is no operation in 3 minutes after pressing “On/Off Button” for more than 3 seconds, then the Wi-Fi function will stop flashing and disappear from the screen.
- 2) If you need to re-connect your Wi-Fi for the appliance, repeat step 3.